








SLIDING DOOR SYSTEMS: ASSEMBLY INSTRUCTIONS STOPPER AND CEILING-MOUNTED END CAP (S42)

V2017.1

ASSEMBLY:





If you would like to attach the stopper to the top track without end cap, take the included silicone bumper and put it in the designated hole (Fig. 2).



If you would like to insert an end cap, you must use a black rubber stopper (Fig. 6). Put the stopper on the end cap in the designated position and attach it to the end cap with the black rubber bumper and screw.

PREPERATION / ASSEMBLY

INSTALLATION:



Push the end cap with stoppers into the top track and mark the location of the holes on the top track. Drill holes in top track and re-insert end cap with stoppers into top track and screw to blocking in ceiling with appropriate screws.